



INSTALL POLYWRAP ON FIRE HYDRANT BARREL TO THE GROUND SURFACE BEFORE INSTALLING TRACER WIRE SYSTEM. DO NOT COVER WEEP HOLES WITH POLYWRAP.

Revised: February 2015

City of Madison  
Engineering Department  
Hydrant  
Connection



PO Box 308  
116 W. Center Street  
Madison, SD 57042  
Phone: (605)256-7514  
Fax: (605)256-7511